

BLACK JACK™

TRAILER JACK


How to Replace the EXT\RET Switch

Warning: Disconnect power before commencing.

The EXT\RET switch is easy to replace. Just follow these steps.

EXT\RET Switch lugs

The switch has top and bottom plastic lugs that hold it in place.



To remove the switch, take a flat blade screwdriver and gently pry the switch out at the top and the bottom. Take it slowly and the switch will gradually come out.



There are 3 rows of 2 terminals. The top and bottom operate the Extend and Retract functions. The middle 2 terminals are the power and negative wire for the 12-volt motor.



When the switch is out, use the flat blade screwdriver to remove one terminal at a time. Once the terminal is removed, place it in the same position on the new switch.



When all 6 terminals are replaced, gently push the new switch into the housing until it locks in place.

Reconnect power and test the switch operation.

All done, easy!

